

IMPERIAL ELECTRICAL

Owner's



Manual

Congratulations – The Zeppelin is Yours!!!

A five-year, labor of love. The distillation of a lifetime's pursuit of that remarkable, magical tone. To ensure your maximum enjoyment of this gateway to the most sublime of classic rock tones.... Read on....

Controls

The Zeppelin is made up of two separate pedals. You can use each independently or use them simultaneously. We love using them simultaneously. That's when the heavens begin to open, the seas begin to part and when sound as we knew it ceases and is replaced with a glorious, sonic singularity.

Plexi Preamp Section – Left hand controls

PR: This controls the preamplifier volume – you can view this as the overdrive control – turn it up = more dirt. Turn it down = less dirt.

TO: This controls the tone of the Plexi section. A unique and original control that allows the overall tone and feel of the signal to be modified by one single dial. Turn it clockwise for more bite, turn it counterclockwise for more bottom end.

PO: Plexi Out – this controls the overall output level of the Plexi preamplifier. The master volume.

Left Footswitch: This engages and disengages the Plexi Preamp section. The central LED will glow red when it's engaged. (True Bypass)

Echoplex Preamp Section – Right hand controls

PL: Echoplex section gain control. Turn it clockwise for more gain, turn it counterclockwise for less gain. When the Echoplex preamp section is engaged you will find that the tone is "tightened/ refined/ focused" as well as allowing the signal to be boosted, reduced or maintained in relation to unity gain.

Right Hand Footswitch: This engages the Echoplex Preamp section. When engaged the central LED will glow green.

LED – will glow Red when the Plexi pre is engaged, Green when the Echoplex is engaged and Orange when both Plexi and Echoplex sections are engaged simultaneously. (True Bypass)

DC Power Socket: Insert your DC 9-volt power adapter here. Tip Negative.

Right Jack Socket: Connect your guitar here

Left Jack Socket: Connect your amplifier here.

Power: Please use a regulated, DC, 9 volt power supply with a 2.1mm, tip negative, plug, to power your Zeppelin. **The Zeppelin does not run on batteries.**

The Zeppelin draws 70mA of current.